


SPATIAL AWARENESS


Coordinates, transformations and uncertainty

Teresa Vidal-Calleja


ROBOTIC SYSTEMS - MODEL BASED




ROBOTIC SYSTEMS – MODEL/DATA DRIVEN




ROBOTIC SYSTEMS – DATA DRIVEN




ROBOTIC SYSTEMS – DATA DRIVEN



ROBOTIC SYSTEMS – DATA DRIVEN



ROBOTIC SYSTEMS - MODEL BASED




SPATIAL AWARENESS

Robot Pose – position and orientation


- 2D **position and heading** of a vehicle
- angular position of each joint in a robot arm
- 3D **position and orientation** of an aerial vehicle or the tool at the end of the robot arm



Spatial representation of the world



Estimation algorithms to maintain the state of the robot and/or world and to filter the sensor noise




through Sensors (and models)

SPATIAL AWARENESS

We need to

- define the coordinate reference frames and find the transformation between fixed coordinate frames (**calibration**)
- have a systematic way represent poses (and world)
- infer the current robot pose (**estimation**) and/or understand the world through sensor observations and models



ROBOT SENSING

Proprioceptive sensors measure the state of the robot itself

- the angle of the joints on a robot arm
- the number of wheel revolutions on a mobile robot
- the accelerations and angular velocities of drones and ground robots


Exteroceptive sensors measure the state of the world with respect to the robot

- a simple contact switch on a vacuum cleaner robot to detect collision
- a GPS receiver that measures distances to an orbiting satellite constellation
- a compass that measures the direction of the Earth's magnetic field relative to the robot's heading
- a depth sensor that can sense distance and direction to the obstacles in the field of view (fov)
- a vision sensor that provide images that can be processed to understand the world in the fov


SENSING POSITION

Optical encoders (**proprioceptive**)

- used to measure the angular position of each joint in a robot arm
- they can also be used to measure the rotation of each wheel of a vehicle for odometry
- highly noisy



Optical wheel encoder




Encoding disk



SENSING POSE

Inertial Measurement Unit (**proprioceptive**)

- measures the proper linear accelerations and angular velocities with accelerometers and gyroscopes
- highly noisy
- require bias estimation and gravity alignment



IMU



Vicon System



Motion Capture Systems (**proprioceptive/exteroceptive**)

- optical positioning (mainly indoors) through infrared cameras and markers with infra-red retro reflective material
- Very accurate

SENSING WITH VISION

Cameras (**exteroceptive**)

- Monocular / Stereo
 - Monochrome / RGB
 - Infrared / Thermal / Multispectral
 - Depth
-
- Requires image processing
 - monocular is subject to scale
 - can provide spatial and appearance information
 - noise depends on algorithms



Visual




Infrared

SENSING WITH DEPTH SENSORS


Depth Cameras (exteroceptive)

- Measures 3D information
- Similar to Stereo/ can be combined with Stereo
- Structure Light or Time of Flight
- highly noisy in depth (0.6 – 5m)
- can provide spatial and appearance information




Lidars(exteroceptive)

- Scanning (rotating elements – mirror)
- returns distance and bearings to the nearest objects
- range 1-100m
- can be accurate



REPRESENTING POSE - POSITION


Position in space is represented using a vector for the x, y and z coordinates of a point:



Define the origin and axes conventions

REPRESENTING POSE - ORIENTATION

If the axes point in different directions, then the point has different coordinates:



This rotation can be represented by a 3x3 matrix:

$$\begin{pmatrix} 3.54 \\ -0.707 \\ 2 \end{pmatrix} = \begin{bmatrix} 0.707 & 0.707 & 0 \\ -0.707 & 0.707 & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} 3 \\ 2 \\ 2 \end{pmatrix}$$

ROTATION

Rotations in 3D are represented by 3x3 matrices
But not just any 3x3 matrix – what are the rules?

$$R = \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix}$$

Lengths must be preserved: $|v| = |Rv|$

Angles must be preserved: $v_1 \cdot v_2 = (Rv_1) \cdot (Rv_2)$

PRESERVING LENGTHS

$$|v| = |Rv|$$

$$\begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} \begin{pmatrix} 1 \\ 0 \\ 0 \end{pmatrix} = \begin{pmatrix} r_{11} \\ r_{21} \\ r_{31} \end{pmatrix} \quad \text{so} \quad \begin{vmatrix} r_{11} \\ r_{21} \\ r_{31} \end{vmatrix} = 1$$

This means that every column of R must be unit length

PRESERVING ANGLES

$$v_1 \cdot v_2 = (Rv_1) \cdot (Rv_2)$$

$$\begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} \begin{pmatrix} 1 \\ 0 \\ 0 \end{pmatrix} = \begin{pmatrix} r_{11} \\ r_{21} \\ r_{31} \end{pmatrix} \quad \text{and} \quad \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} \begin{pmatrix} 0 \\ 1 \\ 0 \end{pmatrix} = \begin{pmatrix} r_{12} \\ r_{22} \\ r_{32} \end{pmatrix}$$

$$\begin{pmatrix} r_{11} \\ r_{21} \\ r_{31} \end{pmatrix} \cdot \begin{pmatrix} r_{12} \\ r_{22} \\ r_{32} \end{pmatrix} = 0$$

Different columns of R are orthogonal

$R^T R$ – ORTHOGONAL MATRIX

What is $R^T R$?

$$RR^T = \begin{bmatrix} r_{11} & r_{21} & r_{31} \\ r_{12} & r_{22} & r_{32} \\ r_{13} & r_{23} & r_{33} \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} = \begin{bmatrix} 1 \\ \\ \end{bmatrix}$$

↑

Because this is unit length

$R^T R$

What is $R^T R$?

$$RR^T = \begin{bmatrix} r_{11} & r_{21} & r_{31} \\ r_{12} & r_{22} & r_{32} \\ r_{13} & r_{23} & r_{33} \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix}$$

Because these are orthogonal

$R^T R$

What is $R^T R$?

$$R^T R = \begin{bmatrix} r_{11} & r_{21} & r_{31} \\ r_{12} & r_{22} & r_{32} \\ r_{13} & r_{23} & r_{33} \end{bmatrix} \begin{bmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{bmatrix} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

So $R^T = R^{-1}$

This means that R^T is also a rotation (it rotates back)

So rows of R are also unit length and orthogonal

These matrices form a group called **SO(3) – Special Orthogonal Group**

ROTATING ABOUT THE AXES


The matrices that represent rotations about the x y and z axes are:

$$R_x = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos(\theta_x) & -\sin(\theta_x) \\ 0 & \sin(\theta_x) & \cos(\theta_x) \end{bmatrix} \quad R_y = \begin{bmatrix} \cos(\theta_y) & 0 & \sin(\theta_y) \\ 0 & 1 & 0 \\ -\sin(\theta_y) & 0 & \cos(\theta_y) \end{bmatrix}$$

$$R_z = \begin{bmatrix} \cos(\theta_z) & -\sin(\theta_z) & 0 \\ \sin(\theta_z) & \cos(\theta_z) & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

TRANSLATION

Move the origin to a different place:




This shift (translation) can be represented by adding a vector:

$$\begin{pmatrix} 1 \\ 1 \\ 2 \end{pmatrix} = \begin{pmatrix} 3 \\ 2 \\ 2 \end{pmatrix} + \begin{pmatrix} -2 \\ -1 \\ 0 \end{pmatrix}$$

BOTH TRANSLATION AND ROTATION

We can move the origin *and* rotate the frame



This can be represented by a rotation matrix and adding a vector:

$$\begin{pmatrix} 1.414 \\ 0 \\ 2 \end{pmatrix} = \begin{pmatrix} 0.707 & 0.707 & 0 \\ -0.707 & 0.707 & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 3 \\ 2 \\ 2 \end{pmatrix} + \begin{pmatrix} -2.121 \\ 0.707 \\ 0 \end{pmatrix}$$

HOMOGENEOUS COORDINATES

Position vectors can be extended to 4 dimensions by adding a 1 at the end

This representation of position is called **homogeneous coordinates**

This lets us use a matrix to apply a translation:

$$\begin{bmatrix} 1 & 0 & 0 & 2 \\ 0 & 1 & 0 & 3 \\ 0 & 0 & 1 & 4 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} x \\ y \\ z \\ 1 \end{pmatrix} = \begin{pmatrix} x+2 \\ y+3 \\ z+4 \\ 1 \end{pmatrix}$$

HOMOGENEOUS COORDINATES

Position vectors can be extended to 4 dimensions by adding a 1 at the end

This representation of position is called **homogeneous coordinates**

This lets us use a matrix to apply a translation:


This is the translation that gets added to x y z

$$\begin{bmatrix} 1 & 0 & 0 & 2 \\ 0 & 1 & 0 & 3 \\ 0 & 0 & 1 & 4 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} x \\ y \\ z \\ 1 \end{pmatrix} = \begin{pmatrix} x+2 \\ y+3 \\ z+4 \\ 1 \end{pmatrix}$$

HOMOGENEOUS COORDINATES

Translations and rotations can be applied at the same time in a single matrix

Using the previous example




$$\begin{pmatrix} 1.414 \\ 0 \\ 2 \\ 1 \end{pmatrix} = \begin{bmatrix} 0.707 & 0.707 & 0 & -2.121 \\ -0.707 & 0.707 & 0 & 0.707 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} 3 \\ 2 \\ 2 \\ 1 \end{pmatrix}$$

HOMOGENEOUS COORDINATES

Translations and rotations can be applied at the same time in a single matrix

Using the previous example



The rotation goes here The translation goes here

$$\begin{pmatrix} 1.414 \\ 0 \\ 2 \\ 1 \end{pmatrix} = \begin{bmatrix} 0.707 & 0.707 & 0 & -2.121 \\ -0.707 & 0.707 & 0 & 0.707 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} 3 \\ 2 \\ 2 \\ 1 \end{pmatrix}$$

Add a 1 to the end of the vectors

HOMOGENEOUS TRANSFORMATION MATRIX

$R \in SO(3) \rightarrow$ Special Orthogonal Group

$t \in \mathbb{R}^3 \rightarrow$ Set of Real Values (3 dimensions)

$$T = \begin{bmatrix} R & t \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} = \begin{bmatrix} r_{11} & r_{12} & r_{13} & x \\ r_{21} & r_{22} & r_{23} & y \\ r_{31} & r_{32} & r_{33} & z \\ 0 & 0 & 0 & 1 \end{bmatrix} \in SE(3)$$

SE is the **Special Euclidean Group**

Describes both **rotation** and **translation** in 3-dimensional Euclidean space

INVERSE OF THE TRANSFORMATION MATRIX

Transform from {1} to {2}:

$$\mathbf{T}_1^2 = \begin{bmatrix} \mathbf{R}_1^2 & \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix}$$

Then its opposite, {2} to {1} is:

$$\boxed{\mathbf{T}_2^1 = \begin{bmatrix} (\mathbf{R}_1^2)^T & -(\mathbf{R}_1^2)^T \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix}}$$

Such that:

$$\mathbf{T}_2^1 = (\mathbf{T}_1^2)^{-1}$$

Multiply the 2 transforms:

$$\begin{aligned} \mathbf{T}_1^2 \mathbf{T}_2^1 &= \begin{bmatrix} \mathbf{R}_1^2 & \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} \begin{bmatrix} (\mathbf{R}_1^2)^T & -(\mathbf{R}_1^2)^T \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} \\ &= \begin{bmatrix} \mathbf{R}_1^2 (\mathbf{R}_1^2)^T & -\mathbf{R}_1^2 (\mathbf{R}_1^2)^T \mathbf{t}_1^2 + \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} \\ &= \begin{bmatrix} \mathbf{I} & -\mathbf{t}_1^2 + \mathbf{t}_1^2 \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} \\ &= \begin{bmatrix} \mathbf{I} & \mathbf{0} \\ \mathbf{0}_{1 \times 3} & 1 \end{bmatrix} = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} = \mathbf{I} \quad \checkmark \end{aligned}$$

COORDINATE FRAMES

The rotation matrix and the translation vector describe the change in coordinate frame


We can transform points from one coordinate frame to another

$$p_w = T_w^c T_c^o p_o$$

We can find a coordinate transformation through the kinematic chain

$$T_e^o = T_e^r T_r^w T_w^c T_c^o$$

$$T_e^o = (T_r^e)^{-1} (T_w^r)^{-1} T_w^c T_c^o$$



SENSOR UNCERTAINTIES

Sensors are noisy!

Suppose we are measuring a pen using ruler


One measurement gave 10.1cm

Another measurement gave 10.3cm






What value would you take for the length of the pen?

$$x = \frac{10.1+10.3}{2} = 10.2$$




NORMAL DISTRIBUTIONS

Measurement uncertainties are usually represented with **normal distributions** (often with mean zero)



UNIVARIATE (1D) GAUSSIAN PROBABILITY DENSITY FUNCTION




$p(x) \sim N(\mu, \sigma^2)$: Mean

$$p(x) = \frac{1}{\sqrt{2\pi}\sigma} e^{-\frac{1}{2}\frac{(x-\mu)^2}{\sigma^2}}$$

Variance
Scaling to
sum to 1

MULTIVARIATE (2D) GAUSSIAN PROBABILITY DENSITY FUNCTION



$$p(\mathbf{x}) \sim N(\boldsymbol{\mu}, \boldsymbol{\Sigma}) :$$

$$\boldsymbol{\mu} = \begin{pmatrix} \mu_x \\ \mu_y \end{pmatrix} \quad \boldsymbol{\Sigma} = \begin{bmatrix} \sigma_x^2 & \sigma_{xy} \\ \sigma_{xy} & \sigma_y^2 \end{bmatrix}$$

Cross correlation

Scaling to sum to 1

$$p(x) = \det(2\pi\Sigma)^{-\frac{1}{2}} \exp \left(-\frac{1}{2}(x - \boldsymbol{\mu})^T \boldsymbol{\Sigma}^{-1} (x - \boldsymbol{\mu}) \right)$$

Mean

Covariance

Matrix

COMBINING MEASUREMENTS

Suppose we now have and a ruler and a Vernier Caliper which is 10x accurate


Ruler measurement gave 10.1cm

Vernier measurement gave 10.3cm

What value would you take for the length of the pen?

$$x = \frac{1*10.1 + 10*10.3}{1+10} = 10.27$$

weighted average



COMBINING MEASUREMENTS

Because the measurements are independent the joint probability is the product

$$\left. \begin{array}{l} X_1 \sim N(\mu_1, \sigma_1^2) \\ X_2 \sim N(\mu_2, \sigma_2^2) \end{array} \right\} \Rightarrow p(X_1) \cdot p(X_2) \sim N\left(\frac{\sigma_2^2}{\sigma_1^2 + \sigma_2^2} \mu_1 + \frac{\sigma_1^2}{\sigma_1^2 + \sigma_2^2} \mu_2, \frac{1}{\sigma_1^{-2} + \sigma_2^{-2}} \right)$$

$$\left. \begin{array}{l} X_1 \sim N(\mu_1, \Sigma_1) \\ X_2 \sim N(\mu_2, \Sigma_2) \end{array} \right\} \Rightarrow p(X_1) \cdot p(X_2) \sim N\left(\frac{\Sigma_2}{\Sigma_1 + \Sigma_2} \mu_1 + \frac{\Sigma_1}{\Sigma_1 + \Sigma_2} \mu_2, \frac{1}{\Sigma_1^{-1} + \Sigma_2^{-1}} \right)$$